

SMALL Decal Installation



1. Measure where you want your decal to be. Then tape in place on 1 side only to use as a hinge, using regular masking tape. Place your tape on the top, bottom or either side, however you feel more comfortable.



2. Peel the bottom WAXY LINER layer away from the DECAL and MASK LAYER starting at the opposite side of the masking taped hinge, and slowly remove it.



3. Wet method is suggested for beginners and larger decals. To use the wet method placement, spray the smooth surface with a mixture of soap and water.

Wet Application Fluid: Wet method is how you install larger images with NO BUBBLES in it (and a MUST for frosted vinyl to ASSURE every bubble is removed), being wet allows you to squeegee out the air bubbles trapped inside before it sticks to the surface. You can make your own application fluid with 4 drops of dishwashing liquid (dawn, joy, or baby shampoo etc.) to 1 quart of water in a spray bottle.



4. While still holding the PRE-MASK layer away from the smooth surface. Use a squeegee, credit card or any plastic straight edge to help in application. Start from the side with the tape and gently work away from the tape and squeegee out all water and soap.

(Note: if you do not have a squeegee use your fingertips or the sharp edge of a credit card, plastic ruler or similar object)



5. Use your squeegee and apply pressure from the middle to the outward sides, this will remove all water and start the decal adhesion. Let sit for 5 minutes before removing. If your decal appears to not be sticking the fluid is still behind the decal, just squeegee again and let sit for 10-15 minutes.

The decals have a pressure sensitive adhesive the harder you rub the harder it sticks, also the longer you let it sit the stronger the adhesive will adhere.



6. Now you're ready to pull off your PRE-MASK layer and view your decal. Gently pull it off, if you see some vinyl start to come up with the PRE-MASK then lay it back down, squeegee, and wait a few minutes and try again.

Prick any air bubbles with a pin and rub down. Be sure that outer edges of decal are rubbed down smoothly and all liquid is forced out. This is essential for proper adhesion.